

ADB Potenza Remote Control

Device Selection

Send commands to TV, audio, DVD, auxiliary device or set top box

DVR LIST

For future use

MENU

Displays Menu Bar

Arrow Buttons

Move highlight in system screens

GUIDE

Displays Guide

DAY - / DAY +

Jumps Guide 1 day ahead or back

Function Buttons

Reserved

VOL + / -

Adjust volume

MUTE

Toggle audio on or off

Number Pad

Enter a channel number or PIN

Power

Turn a selected device on or off

Playback Controls

Control playback of DVD, PVR or VOD

Record

Begin PVR recording

Info

Display the Info Bar

OK

Enter a choice you have made

Exit

Close any screen and return to TV

PG + / -

Jump Guide 1 page up or down

CH +/-

Change the channel

VOD

For future use

LAST

Return to previous channel

CC

Toggles closed captions on or off

